Demo Mode for B36 (FDBM)



Fridge super	°C/°F fresh	light settings eco	connect	VitaFresh pro	① on/off	alarm off menu	change filter super	Freezer
				BOSCH				100

Function	Operation	Display	Comment
Start Demo Mode	 Plug in unit Within 10 seconds press the "alarm off" button. Hold down. Within the first 15 seconds, you should hear 3 beeps. Release the button after you hear the 3 beeps. "alarm off" should be illuminated. 	 Alarm LED turns on indicating active demonstration mode. Normal control panel display Normal lighting display Will not cool 	Demo mode must be activated within first 15 seconds of turning on unit. If you see "99" in the freezer segment, you must restart after 10 minutes.
End Demo Mode	 Unit needs to be re-started if running. If powered off, the unit needs to run at least 30 seconds. After the first 30 seconds press the "alarm off" button. Hold down. Within the first 15 seconds, you should hear 3 beeps. Release after you hear the 3 beeps. 	Alarm LED turns off. Normal operation will begin.	Appliance is running at least 30s.

NOTE:

- Actions must be done within the first 15s after switching on the appliance (to start demo) and after the first 30s (to end demo mode)
- Even if there is a power outage, demo mode stays on the unit until it is manually turned off.
- In demo mode the unit will not cool only the lighting and the control panel will be active.