

# Simple Solutions



**Rackmatic®** – one step adjustment for up to 9 rack positions — fits taller items like stemware in the middle rack while leaving room for pots and pans below

**FlexSpace® Tines** – fold down every other tine in one simple step, making room for larger, bulkier items



**EasyGlide™** – smooth-rolling racks with an effortless glide and the Benchmark® **EasyGlide™ Plus** wheels have ball bearings to deliver a smooth glide with fully loaded racks

**3<sup>rd</sup> Racks** – two 3<sup>rd</sup> rack options provide additional loading space and flexibility to load large utensils and small dishes



## Conveniently Reorder Products

- Set up directly through the **Amazon Alexa** app  
*Activate dishwasher skill > Set up reorders*
- **Home Connect®** tracks detergent tab inventory with each cycle
- When inventory is low, additional tablets will be ordered through **Amazon Smart Reorder**
- Once package is delivered, the ordered quantity is added back into the tablet counter

